


# Power V-Blade Joystick Controller MSC03809 Parts Breakdown



**Figure 1.** Power V-Blade Joystick Control Parts Breakdown

G10055

Reference Number	Part Number	Description
1	MSC04087	Switch, Raise/Lower V-Blade
2	MSC04718	Handle, Joystick V-Blade
3	MSC04267	Switch, Joystick Micro
4	MSC04086	Switch, Joystick On/Off
5	MSC04209	Label, Joystick V-Blade
6	MSC04085	Diode Pack, Replacement